



PATTENDEN MACHINERY LTD

Parts Catalogue

Machine: Grouse

Component: Whole machine

INDEX

Head, drive components, brushes, belts

Basket & Operating Arms

Hydraulic Pump & Pipes

Engine, Engine Components, Filters & Covers

Rear axle view, diff lock/ cable, steering arms/rods

Brake disc, drive shaft and motor/pipes

Rear tyres and wheels

Rear mount for head, Main hydraulic pump

Hydraulic oil radiator and pipes

Apple Paddle, drive motor, pipes and rubber paddles

Head brush gear /bearings

Paddle arms, hoses, ancillary components

Steering head / steering joints / ancillary joints

Front wheel drive motor & hoses

Front mounted Hydraulic valves, front pipework layout

Steering wheel valve / valves / pipework & seat

Fuel tank and hydraulic tank

Drivers levers, valves, throttle, ignition box / pipework

Drivers forward / reverse mechanism and micro switch

Big wheel and cab models

GR189 PB2729 GR010 GR087 PB8897 GR437*

Picture 1



Picture 1 Parts:

GR189 = Skid (NB: size of skid specific to model. Please confirm serial number when ordering)

PB2558/2 = Bootlace (single)

PB2729 = Bootlace clamp bar

GR010 = Front steel sheet


GR087 = Front entry flap

PB8897 = Head suspension spring

GR437 = Head lift hydraulic ram

GR437SK = Seal kit for GR437

***ram seal kits vary depending on
number of black bands on ram.**



Picture 2 Parts:

PB8922 = Grouse head brush section

GR277 / PB8558 = Outer bearings (20mm). Flushback or lipback depending on build.


GR024 = Lip roller shaft

GR312 = 20mm bearing plates

GR176 = Head rotor shaft (GR474 on newer models)

PB2558 = Head rubber cover

Picture 3: Grouse head sprockets and chains




Picture 3 Grouse Head Sprockets and Chains

- GR052 = Lip roller drive chain (08B) + PB8452CL
- GR121 = Head rotor double sprocket (20/24tooth)
- GR122 = Idler tension sprocket (16tooth)
- GR025 = Lip roller sprocket (30tooth) uses GR256 taper bush
- GR051 = Rotor drive chain (08B) + PB8452CL
- GR026 = Rotor motor sprocket (24tooth) uses PB8370 taper bush

**GR277 lip roller bearing + GR312 bearing
plates**

Picture 4



**GR312 (Plates for
20mm bearing)**

GR075

GR076

Picture 5



GR031

**GR075
(locking ring)**

PB-8922



Picture 6



GR030

Picture 7





GR521 GR520 GR008 GR016 GR017 GR044 GR024 PB2558

Picture 10



GR012

GR422

GR388
(rod)

GR422

Picture 11



GR161

GR439

GR161

Picture 12



Safety
rubber

1

GR170


2

GR438

GR013

3

Picture 13



PB8893/
1 or 2

GR388

GR297

Picture 14



**PB8893/
1 or 2**

GR016AP

**PB8893/
1 or 2**

Picture 15




GR012

GR060


Picture 16



Picture 17



Picture 18



1

2

3

Picture 19





GR198

Catch

GR009

Picture 20






Picture 23




PB119620-34822
PB117990
PB8392
1
GR220
(TN82)
2
3
4
5
6

Picture 24



1 2 3 4 5 6 7

Picture 25



GR138

PB08122/1

GR372

GR317/
416

Picture 26




Ram lock

2

3

Silencer

Picture 27



CU068


GR118

1

2

3

Picture 28



PB-BB049

1

2


3

Picture 29



PB-BB049 **GR015**

Picture 31



1 **2** **GR363 (seal)**

Picture 32



1

see pic 26

GR071

2

Picture 33



GR106

GR110/
GR111



GR112

Key
(stock item)

GR510

Picture 34





1

2

Picture 37



Tyres: GR364 (23x10.5-12)
 GR282 (20x8.00-10 4PR)
 GR408 (20x8.00-10 10PR)

GR053 (nut)
 GR054 (stud)
 GR501 (bolt)

Picture 38



CU068

2

3

Picture 39



Picture 40



GR082

1


2

3


Picture 41





Picture 42




Picture 43







- 1
 - 2
 - 3
 - 4
 - 5
 - 6
- Picture 46




- 1
 - 2
 - 3
 - 4
 - 5
 - 6
- Picture 47





Picture 48




Picture 49







Picture 52



Picture 53




Picture 54



Picture 55






3 4 5 6 7

Picture 58



1 2 3

Picture 59



Picture 60




1 2 3 4 5 6 7 8 9 10

Picture 61



1

Picture 62



GR041

Picture 63



PB-8008 >2008

PB-8021 2008>

Picture 64



1 2 3 4 5

Picture 65



1 2 3 4 5 6 7 8 9 10 11 12

Picture 66



1 2 3 4

Picture 67



BIG WHEEL & CAB


- 1
- 2
- 3
- 4
- 5
- 6
- 7

Picture 68



- 1
- 2
- 3
- 4
- 5
- 6

Picture 69



1

Picture 70



1

2

Picture 71



Grouse Parts List

GR001: Main chassis

GR002: Toolbox lid

GR003: Foot pedal spacer

GR004: Basket cradle

GR005: Side paddle end plate

GR006: Inner blade rubber support

GR007: Outer blade rubber support

GR008: Rotor cover pin

GR009: Engine Bonnet

GR010: Rolled galvanised front sheet

GR011: Front wheel support assembly (leg)

GR012: Basket

GR013: Parallel link (bare)

GR014: Side paddle skirt bracket

GR015: Rear steering stops

GR016: Head (bare)

GR017: Auger (1.7m long) NB: Black Grouse auger = 2.1m long

GR189: Skid